



Nice USA Inc.



# Re-Programming ERA-MAT

## WITH A TRANSMITTER

1. Disconnect Power to the Motor, Wait 2 Seconds and Reconnect power to the motor  
The motor will perform **2 Movements**, Press and Hold the Square Key until **3 movements** are performed then **release the square Key**. The motor and transmitter are now married.
2. Bring your shutter or screen to a position you desire, press and hold the **square key until 2 movements are performed**, release the key, Press the square button again **until 4 movements** are performed, then release, Now **press and hold the up key** on the transmitter until **2 movements are performed**, then release. Now press the **Up or Down key until the desired position is reached**, you can pulse it for precision, once the desired position is reached **Press and Hold the square Key and wait for 3 movements then release**. Your upper limit is set
3. Now Run the shutter in the Opposite direction and repeat the process again
4. Press and hold the **Square Key, 2 movements**, then release. Press and hold the **Square Key** again **4 movements and release**, Now press the **down key and wait for 2 movements** and **release**. Now press whichever key (Up or down) will bring it down to the desired position, pulse it for a precision setting, **Then press and Hold the Square Key and release after 3 movements**. Now the limits are set. Try Them

### Add a Transmitter

New Transmitter—Press and Hold the Square Key 8 Seconds (no movement)-----**8 seconds**

Old Transmitter – Pulse any button Three Times, for simplicity Pulse square Key-**3 Presses**

New Transmitter – Pulse the Square Key one Time to complete the procedure-----**1 Press**

### Deletion of Memory

Press and Hold Square **Key 5 seconds until 2 movements** then Release, Then the **Up Key 5 seconds** until **3 movements, and release**. Now the **Square Key 5 seconds, 3 movements** then release, and Now the **down Key 5 seconds and 3 movements, and release**. Now **Press and Hold the UP and DOWN together 5 Seconds, 5 movements**, and **Release together**. Congratulations you have deleted the memory



[www.niceapollo.com](http://www.niceapollo.com)  
Nice USA Inc. 12625 Wetmore Rd. San Antonio TX 78247  
Phone 210-545-2900—Fax 210-545-2915



